

[← All blog posts](#)

Quantum Noise Spectroscopy

Characterising and suppressing noise in QruiseOS

Table of Contents



Improving gate fidelities in quantum processing units (QPUs) requires effective suppression of decoherence. Decoherence arises from environmental noise, and understanding this noise is crucial for mitigation. [Quantum noise spectroscopy](#) (QNS) is a valuable method for this, enabling the qubit to act as a noise spectrometer. By measuring the qubit's response to specially designed control sequences, QNS helps identify and target specific noise features, aiding in the development of tailored decoherence suppression strategies.

Control schemes for QNS

Various control schemes have been used to perform QNS, tailored to the spectral properties of the noise and the frequency range of interest, as summarised in the table below. Over the past two decades, these schemes have been experimentally implemented across a variety of qubit platforms, including diamond [nitrogen vacancy centres](#), [nuclear spins](#), [superconducting quantum circuits](#), [semiconductor quantum dots](#), and [trapped ions](#).

Method	Statistics of noise	Reconstructed spectral property	Reconstruction frequency range
Repeated Ramsey spectroscopy	Gaussian, Stationary	Dephasing noise power spectral density (PSD) and control field inhomogeneities	mHz to 100s of Hz
Dynamical decoupling QNS	Gaussian, Stationary	Dephasing noise PSD and control field inhomogeneities	few Hz to 10s of MHz
Non-Gaussian Dynamical decoupling QNS	Non-Gaussian, Stationary	Higher orders spectrums of dephasing noise and control field inhomogeneities	few Hz to 10s of MHz
Spin-locking QNS	Gaussian, Stationary	Dephasing noise PSD	few Hz to 100s of MHz
Rabi spectroscopy	Gaussian, Stationary	Dephasing noise PSD and control field inhomogeneities	few MHz to over a GHz
T₁ spectroscopy	Gaussian, Stationary	Transverse noise PSD	Around qubit frequency

Dynamical decoupling sequences in QruiseOS

In [QruiseOS](#), we implement a method based on [dynamical decoupling sequences](#) to measure the power spectral density (PSD) of the dephasing noise experienced by the qubit. Specifically, we use a [Carr-Purcell-Meiboom-Gill](#) (CPMG) dynamical decoupling sequence which consists of a $[\tau - \pi - \tau]$ block repeated N times between two $\frac{\pi}{2}$ pulses, where τ is the free evolution time. With careful consideration, we can correlate the noise PSD to a qubit observable measured under such a sequence.

Let's understand it with an example involving the off-diagonal elements of the qubit density matrix, i.e., coherences as observables:

For a qubit subjected to surrounding noise and a control sequence, as $t \rightarrow \infty$, the coherence, $C(t)$, decays as

$$C(t \approx 2N\tau) = e^{-\chi(t)},$$

where the attenuation function

$$\chi(t) = \frac{1}{2\pi} \int_0^\infty |F(\omega, t)|^2 S(\omega) d\omega.$$

Here, $S(\omega)$ is the PSD, which describes the effects of noise, and $F(\omega, t)$ describes the effect of the control sequence.

For a CPMG sequence,

$$F(\omega, t) \approx \frac{4t}{\pi^2} \sum_{l=0}^{\infty} \frac{1}{(2l+1)^2} \delta(\omega - \omega_l),$$

which leads to the attenuation function

$$\chi(t) = \frac{4t}{\pi^2} \sum_{l=0}^{\infty} \frac{1}{(2l+1)^2} S(\omega_l),$$

with $\omega_l = \frac{l\pi}{2\tau}$.

As we can see from the equation above, a CPMG sequence with a specific free evolution time, τ , makes the qubit sensitive to specific noise frequencies determined by $f_l = \frac{\omega_l}{2\pi} = \frac{1}{4\tau}$ and its harmonics, allowing us to directly observe their impact via qubit observables, such as the coherence. By repeating the sequence for different values of τ , it's possible to reconstruct the full noise PSD of the qubit.

If shape of the PSD allows, we can simply ignore the impact of harmonics (truncating the above series to $l = 0$, called [single-delta approximation](#)) and correlate the noise PSD at $\frac{1}{4\tau}$ one-to-one with the qubit coherence. This provides an estimate of the full PSD through


$$S\left(\frac{\pi}{2\tau}\right) = -\frac{4t}{\ln[C(t)]\pi^2}.$$

However, for general PSDs, to properly account for the impact of harmonics, more sophisticated analysis methods are required. In QruiseOS, we provide various analysis methods depending on the shape of the PSD.

QNS in action


Let's see QNS in action by estimating the noise PSD of the $\frac{1}{f^b}$ type, which is ubiquitous in solid state QPUs.

We use a qubit longitudinally coupled to a stochastic process as a noisy QPU. To generate stochastic processes following a specific PSD, we use the Qruise Noise Library, which supports the generation of an extensive class of Gaussian and non-Gaussian noise processes. We then subject the qubit to CPMG sequences with various free evolution times. In the figure below, you can see the simulated coherence for various free evolution times (right) and the corresponding noise PSD (left). The decay of coherence assumes a stretched exponential shape as expected for noise PSDs of the $\frac{1}{f^b}$ type. If $b = 1$, the decay assumes the well-known Gaussian shape.



The coherence data, analysed using sophisticated methods like the [Álvarez-Suter](#) technique, accurately reconstructs the noise PSDs, confirming the efficacy of our noise identification and suppression strategies. You can see in the figure below the compelling comparison between the original and reconstructed PSDs, demonstrating our excellent capability to characterise surrounding noise and consequently shield and stabilise QPUs against it!

Quantum noise spectroscopy using CPMG sequences



At Qruise we are constantly pushing the boundaries of noise estimation, so stay tuned for brand new features coming soon!

Contributors



Kirsty McGhee
Scientific Writer



Deepak Khurana
Quantum Physicist

Share this post

 Share on X

 Share on LinkedIn

Stay informed with our newsletter

Subscribe to our newsletter to get the latest updates on our products and services.

Subscribe



Company

Jobs

Blog

Contact



[Privacy Policy](#)

[Terms of Service](#)

[Imprint](#)

© Qruise GmbH 2026. All rights reserved

European
Innovation
Council



Funded by the European Union. Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or the European Innovation Council and SMEs Executive Agency (EISMEA). Neither the European Union nor the granting authority can be held responsible for them. Grant agreement No 101099538